

Carburetor body installation

- Unscrew needle valve
- Unscrew venturi
- Remove needle valve body & spring
- Remove backplate
- Remove cylinder
- Remove piston
- Stand crankcase upright, drive-plate facing upwards
- Insert prop screw as deep as possible
- Tap with hammer until drive-plate separates from crank
- Unscrew collet
- Wedge flat object between carb body and crankcase and twist. Use a plastic or wooden object and not a metal one to prevent scratches – A med-sized flat screwdriver with the tip taped over for instance is an option. (Carb body is pressed on, not screwed)
- Press in new carb body
- Re-assemble engine

For ease of dis-assembly / assembly we sell the following tools:

- Wrench
- Dis-assembly tool
- Assembly tool